

Introducing our new range of fast fit brackets suitable for DAF and Volvo trucks to reduce fitting time and increase productivity.

- High performance Edbro specification brackets customised to fit standard chassis models
- Ultimate productivity with maximum time saving

Pedestal/Cradle Brackets:

Supplied as a specified option. Contact Edbro for pricing information.



BWA1147 and BWA1148 fast fit option brackets now available for standard DAF chassis.



BWA1149 and BWA1150 fast fit option brackets now available for Volvo day cab chassis

Chassis hinge brackets are also available from Edbro and supplied as standard in all 6x4 and 8x4 tipper kits at no extra cost:

Chassis Hinge Brackets:

Now supplied as standard in all kits the following part numbers refer to fast fit chassis hinge brackets for DAF, Volvo and Scania chassis:

DAF	EBF1349	(2 per kit)
Volvo	EBF1371	(2 per kit)
Scania	EBF1372	(2 per kit)