


Montageanleitung für UT20X
 Notice de pose de la UT20X
 Montage instructies voor UT20X



Installation instructions for UT20X



Valve Type	Pump Port in casting (P)	Tank Port (T)	Cylinder Port (A)	Side Port in casting (A1)	Pressure Switch Port
		Mounting Face			
UT 20X	1" BSP	3/4" BSP	1/2" BSP	1" BSP	1/8" BSP

	Port "T"	Port "A"	Port "A1"	TANK BALANCING PLUG	REMOTE MOUNTING KIT
CX 	SUPPLIED WITH VALVE "O" Ring	SUPPLIED WITH VALVE "O" Ring	SUPPLIED WITH VALVE Plug	/	/
Direct Mount 	SUPPLIED WITH VALVE "O" Ring	SUPPLIED WITH VALVE "O" Ring	To suit 3/4" Hose Adaptor NR611/27 Bonded Seal DPP45H/SC To suit 1" Hose Adaptor NR611/43 Bonded Seal DPP45H/SC	/	/
Remote Mount 	To suit 3/4" Hose Adaptor NR1675 Bonded Seal DPP45F/SC To suit 1" Hose Adaptor NR1676 Bonded Seal 2 X DPP45F/SC	Plug 1/2" NR1687 Bonded Seal DPP45D/SC	To suit 3/4" Hose Adaptor NR611/27 Bonded Seal DPP45H/SC To suit 1" Hose Adaptor NR611/43 Bonded Seal DPP45H/SC	Plug 3/4" NR994 Bonded Seal DPP45F/SC	For 3/4" Hose AK91 For 1" Hose AK92

Member of **JOST**-World

JOST, Germany Tel. +49 6102 295-0, jost-sales@jost-world.com, www.jost-world.com
 JOST, UK, Tel. +44 1204 528888, sales-uk@jost-world.com, www.edbro.com

UT20X Rev: 4
 August 20